

# MOOD HOLIDAY

## Mood Music & Visual Platforms: An Illustrated Reference Guide

Need a reminder on how you currently receive your music or visuals? Just look at your onsite device and use the pictures below to identify your platform. Then, return to the "Already a Client?" section on our holiday website and proceed by choosing the appropriate delivery method.

If none of the pictures below match your platform, please contact our Holiday Support Team at 800 331.3340, option 6, or email us at holiday2015@moodmedia.com and we'll be happy to assist.

### MUSIC - SATELLITE PLATFORMS

#### Encompass SR



#### Dish/Echostar




#### Encompass LE/LE2



#### DBS/Prism (Muzak LLC)




#### DBS/Digital Music Express (DMX Inc)



## MUSIC - IP/INTERNET PLATFORMS

### ProFusion iS




### MBOX



### ProFusion X/XS



## MV/MV2/MV3



## MUSIC - CD/DVD PLATFORMS

Encompass XD



ProFusion D/DS



ProFusion X/XS



## VISUAL PLATFORMS


ProFusion iS



Encompass MV3



ProFusion iS



MVision

